

---

## TABLE OF CONTENTS

---

SECTION	SUBSECTION	PAGE
SAFETY NOTICE .....		III
WHAT'S NEW .....		IV
INTRODUCTION .....		V
<b>01 SERVICE TOOLS AND SERVICE PRODUCTS</b>	01 – Table of contents..... 02 – Service tools..... 03 – Service products.....	01-01-1 01-02-1 01-03-1
<b>02 MAINTENANCE</b>	01 – Table of contents..... 02 – Maintenance chart..... 03 – Maintenance and lubrication .....	02-01-1 02-02-1 02-03-1
	04 – Storage and pre-season preparation.....	02-04-1
<b>03 ENGINE</b>	01 – Table of contents..... 02 – Removal and installation..... 03 – Cooling system..... 04 – Rewind starter.....	03-01-1 03-02-1 03-03-1 03-04-1
<b>04 FUEL SYSTEM</b>	01 – Table of contents..... 02 – Fuel circuit .....	04-01-1 04-02-1
	03 – Carburetor and fuel pump .....	04-03-1
	04 – Air intake silencer .....	04-04-1
<b>05 ELECTRICAL</b>	01 – Table of contents..... 02 – Overview .....	05-01-1 05-02-1
	03 – Charging system .....	05-03-1
	04 – Starting system .....	05-04-1
	05 – Ignition system.....	05-05-1
	06 – Electric shift system .....	05-06-1
	07 – Instruments and accessories .....	05-07-1
<b>06 DRIVE TRAIN</b>	01 – Table of contents..... 02 – Front differential .....	06-01-1 06-02-1
	03 – Rear axle.....	06-03-1
<b>07 STEERING/CONTROL SYSTEM</b>	01 – Table of contents..... 02 – Steering/control systems .....	07-01-1 07-02-1
<b>08 SUSPENSION</b>	01 – Table of contents..... 02 – Front suspension..... 03 – Rear suspension.....	08-01-1 08-02-1 08-03-1
<b>09 BRAKES</b>	01 – Table of contents..... 02 – Hydraulic brakes.....	09-01-1 09-02-1

---