

Fig. 2-10 ① Exhaust plate




Fig. 2-11 ① 6 mm bolts

6. Remove the exhaust plate.

7. Remove the eight 6 mm bolts.




Fig. 2-12 ① 6 mm bolt

Note :

Remove one 6 mm bolt, working through it with a socket. (Special tool)