

# Outboard Models Covered in This Service Manual

## 25 Models

E25DRLEO  
E25DELEO  
E25DTLEO  
E25DREO  
E25DEEO

J25DRLEO  
J25DELEO  
J25DTLEO  
J25DREO  
J25DEEO

## 40 Models

E40REO  
E40RLEO  
E40BAEO  
E40BALEO  
E40EEO  
E40ELEO  
E40TEEO  
E40TELEO  
E40TLEO  
E40TTLEO

40RSM  
40RSLM  
40RSYM  
40RWLP  
40RPP  
40RPLP  
40RPYP

J40REO  
J40RLEO  
J40BAEO  
J40BALEO  
J40EEO  
J40ELEO  
J40TEEO  
J40TELEO  
J40TLEO  
J40TTLEO

## 45 Models

45RSP  
45RSLP  
45RSYP  
45RCEO  
45RCLEO

## 48 Models

E48ESLEO

J48ESLEO

## 50 Models

E50BEO  
E50BELEO  
E50TELEO  
E50TLEO  
E50JEO

J50BEO  
J50BELEO  
J50TELEO  
J50TLEO  
J50JEO

## 55 Models

55RSG  
55RSLG  
55RSYG  
55WMLG